



Village Cabinetry – Measuring Guide

Village Cabinetry will in most cases make job site visits to take accurate measurements, however by providing us with your own initial dimensions you will speed the design process up and receive your preliminary design quicker. By providing correct measurements for your cabinet and/or countertop project you can insure that your initial designs and quotes will be accurate. When you are measuring for cabinetry or countertops, dimensions should be to the nearest 1/8". On almost every cabinetry or countertop job sold, Village Cabinetry will verify all dimensions before ordering occurs. This insures that minimal mistakes are made due to inaccurate measurements.

Please follow these instructions to insure correct measurements, all measurements should be to the nearest 1/8" and should be finished (include drywall) dimensions:

1. Draw a sketch of the space's shape as if you are looking down from above as accurately as possible.
2. Mark all doors, windows, pass-throughs, appliances, sinks or other obstacles such as chimneys, radiators, built-ins (closets, furniture, ect.)

3. Mark all dimensions on all walls in the room
4. Note all doors, windows, pass-throughs dimensions to the nearest 1/8". Be sure to include the trim or woodwork in the overall dimension.
5. Record the dimension from the end of each wall to each door, window or obstacle and the space in between each one.
6. Add any other dimensions that seem to be important. The more dimensions included on the drawing the less chance the designer will be missing a critical dimension.
7. Include the following general information and notes:
 - A. Finished ceiling height include any additional flooring that will increase or decrease the height
 - B. note if any walls, doors, windows, appliances, sinks, built-ins or other obstacles can be moved or removed.
 - C. record anything else that seems to be important. You cannot provide too much information